


TTY232-TAP -- RS-232 to Teletype Current-Loop Interface

Allows RS-232 port to tap into externally-powered (and current-limited) TTY current loop. For half-duplex single loop using 20-60 mA (150V max). Auto-Loop-Polarity provided by bridge D5. Self-powered RS-232 interface, derives V-POS and V-NEG rails from RTS, DTR, and/or TXD lines. Note: laptops may have low-voltage/low-current 232 ports compared to desktop PCs. Best results are obtained when RTS and DTR are driven to opposite voltage levels by PC (one active=positive, one inactive=negative), resulting in stable V-POS and V-NEG rails. If RTS and DTR are both active (positive), V-NEG rail is derived from filtered TXD, which is normally marking (negative). V-NEG rail will rise when data is transmitted -- if it rises above -3V (RS-232 min spec), filter cap C2 may need to be increased, and/or inter-character delays (or extra stop bits) may be needed, to increase TXD's marking time for charging C2. The RS-232 spec calls for the negative level to be less than -3V, but most 232 receivers will accept as negative a level all the way up to ground. If only TXD is connected (no RTS or DTR), V-POS rail is also derived from TXD during transmission -- a break (line spacing) or header string of dummy characters may be needed to charge C1. Tested to 9600 baud with 20-mA/30V loop, and 4800 baud with 60-mA/150V loop.

Open-collector RTS and DTR lines are available for uses such as keying a radio transmitter. Setting RTS or DTR active (positive) will activate Q2 or Q3. Set the other line inactive (negative) to provide V-NEG; V-POS will be provided by TXD. OOPS: Forgot diodes on B-E of Q2 and Q3 to clamp neg level. Add these on next rev, and maybe a second bridge for full duplex. 12-13-00, Gil Smith, gil@vauxelectronics.com

 Vaux Electronics, Inc.		
Title 95-701-A TTY232-TAP .PIC		
Size A	Document Number	Rev A
Date: 12/21/00 Thu	Sheet 1 of 1	